

Important info.:

- Do not unplug or move phones to other jacks or wall plates.
*Open a helpdesk ticket at www.fau.edu/helpdesk for all phone, fax, and analog line moves.
- View and download complete Openstage 40 and 20 User Guides and Quick Reference Guides

NOTE: *SELECT* = *OK* on 3-way Navigation Wheel



MUTE

To temporarily deactivate the microphone on the handset or speakerphone.